marantz®

Model CD5001/CD5001OSE User Guide

CD Player

CLASS 1 LASER PRODUCT
LUOKAN 1 LASERLAITE
KLASS 1 LASERAPPARAT

COMPACT disc DIGITAL AUDIO TEXT

Downloaded Fr

ENGLISH

WARRANTY

For warranty information, contact your local Marantz distributor.

RETAIN YOUR PURCHASE RECEIPT

Your purchase receipt is your permanent record of a valuable purchase. It should be kept in a safe place to be referred to as necessary for insurance purposes or when corresponding with Marantz.

IMPORTANT

When seeking warranty service, it is the responsibility of the consumer to establish proof and date of purchase. Your purchase receipt or invoice is adequate for such proof.

FOR U.K. ONLY

This undertaking is in addition to a consumer's statutory rights and does not affect those rights in any way.

FRANÇAIS

GARANTIE

Pour des informations sur la garantie, contacter le distributeur local Marantz.

CONSERVER L'ATTESTATION D'ACHAT

L'attestation d'achat est la preuve permanente d'un achat de valeur. La conserver en lieu sur pour s'y reporter aux fins d'obtention d'une couverture d'assurance ou dans le cadre de correspondances avec Marantz.

IMPORTANT

Pour l'obtention d'un service couvert par la garantie, il incombe au client d'établir la preuve de l'achat et d'en corroborer la date. Le reçu ou la facture constituent des preuves suffisantes.

DEUTSCH

GARANTIE

Bei Garantiefragen wenden Sie sich bitte an Ihren Marantz-Händler.

HEBEN SIE IHRE QUITTING GUT AUF

Die Quittung dient Ihnen als bleibende Unterlage für Ihren wertvollen Einkauf Das Aufbewahren der Quittung ist wichtig, da die darin enthaltenen Angaben für Versicherungswecke oder bei Korrespondenz mit Marantz angeführt werden müssen.

WICHTIG!

Bei Garantiefragen muß der Kunde eine Kaufunterlage mit Kaufdatum vorlegen. Ihren Quittung oder Rechnung ist als Unterlage ausreichend.

NEDERLANDS

GARANTIE

Voor inlichtingen omtrent garantie dient u zich tot uw plaatselijke Marantz.

UW KWITANTIE, KASSABON E.D. BEWAREN

Uw kwitantie, kassabon e.d. vormen uw bewijs van aankoop van een waardevol artikel en dienen op een veilige plaats bewaard te worden voor evt, verwijzing bijv, in verbend met verzekering of bij correspondentie met Marantz.

BELANGRIJK

Bij een evt, beroep op de garantie is het de verantwoordelijkheid van de consument een gedateerd bewijs van aankoop te tonen. Uw kassabon of factuurzijn voldoende bewijs.

ESPAÑOL

GARANTIA

Para obtener información acerca de la garantia póngase en contacto con su distribuidor Marantz.

GUARDE SU RECIBO DE COMPRA

Su recibo de compra es su prueba permanente de haber adquirido un aparato de valor, Este recibo deberá guardarlo en un lugar seguro y utilizarlo como referencia cuando tenga que hacer uso del seguro o se ponga en contacto con Marantz.

IMPORTANTE

Cuando solicite el servicio otorgado por la garantia el usuario tiene la responsabilidad de demonstrar cuándo efectuó la compra. En este caso, su recibo de compra será la prueba apropiada.

ITALIANO

GARANZIA

L'apparecchio è coperto da una garanzia di buon funzionamento della durata di un anno, o del periodo previsto dalla legge, a partire dalla data di acquisto comprovata da un documento attestante il nominativo del Rivenditore e la data di vendita. La garanzia sarà prestata con la sostituzione o la riparazione gratuita delle parti difettose.

Non sono coperti da garanzia difetti derivanti da uso improprio, errata installazione, manutenzione effettuata da personale non autorizzato o, comunque, da circostanze che non possano riferirsi a difetti di funzionamento dell'apparecchio. Sono inoltre esclusi dalla garanzia gli interventi inerenti l'installazione e l'allacciamento agli impianti di alimentazione.

Gli apparecchi verranno riparati presso i nostri Centri di Assistenza Autorizzati. Le spese ed i rischi di trasporto sono a carico del cliente.
La casa costruttrice declina ogni responsabilità per danni diretti o indiretti provocati dalla inosservanza delle prescrizioni di installazione, uso e manutenzione dettagliate nel presente manuale o per guasti dovuti ad uso continuato a fini professionali.

SVENSKA

GARANTI

För information om garantin, kontakta Marantz lokalagent.

SPAR KVITTOT

Kvittot är ett inköpsbevis på en värdefull vara. Det skall förvaras säkert och hänvisas till vid försäkringsfall eller vidkorrespondens mod Marantz.

VIKTIGT

Fö att garantin skall gälla är det kundens sak att framställa bevis och datum om köpet. Kvitto eller faktura är tillräokligt bevis fö detta.

Downloaded From Disc-Player.com Marantz Manuals

CE MARKING

CE **English**
The CD5001/CD5001OSE is in conformity with the EMC directive and low-voltage directive.

CE **Français**
Le CD5001/CD5001OSE est conforme à la directive EMC et à la directive sur les basses tensions.

CE **Deutsch**
Das Modell CD5001/CD5001OSE entspricht den EMC-Richtlinien und den Richtlinien für Niederspannungsgeräte.

CE **Nederlands**
De CD5001/CD5001OSE voldoet aan de EMC eisen en de vereisten voor laag-voltage.

CE **Español**
El CD5001/CD5001OSE está de acuerdo con las normas EMC y las relacionadas con baja tensión.

CE **Italiano**
Il CD5001/CD5001OSE è conforme alle direttive CEE ed a quelle per i bassi voltaggi.

CE **Svenska**
CD5001/CD5001OSE är tillverkad i enlighet med EMC direktiven och direktiven för lågvoltsutrusning.

English

WARNINGS

- Do not expose the equipment to rain or moisture.
- Do not remove the cover from the equipment.
- Do not insert anything into the equipment through the ventilation holes.
- Do not handle the mains cord with wet hands.
- Do not cover the ventilation with any items such as tablecloths, newspapers, curtains, etc.
- No naked flame sources, such as lighted candles, should be placed on the equipment.
- When disposing of used batteries, please comply with governmental regulations or environmental public instruction's rules that apply in your country or area.
- Make a space of about 0.1 meter around the unit.
- No objects filled with liquids, such as vases, shall be placed on the apparatus.
- When the switch is in the OFF position, the equipment is not completely switched off from MAINS.

Français

AVERTISSEMENTS

- Ne pas exposer l'appareil à la pluie ni à l'humidité.
- Ne pas essayer de retirer le boîtier de l'appareil.
- Ne rien insérer dans l'appareil par les orifices de ventilation.
- Ne manipulez pas le cordon d'alimentation avec des mains mouillées.
- Ne pas recouvrir les ouïes de ventilation avec un objet quelconque comme une nappe, un journal, un rideau, etc.
- Ne placer aucune source de flamme nue, comme une bougie allumée, sur l'appareil.
- Pour mettre au rebut les piles usées, respecter les lois gouvernementales ou les règlements officiels concernant l'environnement qui s'appliquent à votre pays ou région.
- Veiller à ce qu'aucun objet ne soit à moins de 0,1 mètre des côtés de l'appareil.
- Aucun objet rempli de liquide, un vase par exemple, ne doit être placé sur l'appareil.
- Lorsque l'interrupteur est sur la position OFF, l'appareil n'est pas complètement déconnecté du SECTEUR (MAINS).

Deutsch

WARNHINWEISE

- Das Gerät nicht Regen oder Feuchtigkeit aussetzen.
- Die Abdeckung nicht vom Gerät abnehmen.
- Keine Gegenstände durch die Belüftungsschlitze stecken.
- Fassen Sie niemals das Netzkabel mit nassen Händen an.
- Decken Sie die Lüftungsöffnungen nicht mit einem Tischtuch, einer Zeitung, einem Vorhang usw. ab.
- Es dürfen keine Gegenstände mit offener Flamme, wie etwa brennende Kerzen, auf dem Gerät aufgestellt werden.
- Beachten Sie bei der Entsorgung der verbrauchten Batterien alle geltenden lokalen und überregionalen Regelungen.
- Auf allen Geräteseiten muß ein Zwischenraum von ungefähr 0,1 meter vorhanden sein.
- Auf das Gerät dürfen keine mit Flüssigkeiten gefüllte Behälter, wie etwa eine Vase, gestellt werden.
- Wenn der Schalter ausgeschaltet ist (OFF-Position), ist das Gerät nicht vollständig vom Stromnetz (MAINS) abgetrennt.

Nederlands

WAARSCHUWINGEN

- Stel het apparaat niet bloot aan regen of vocht.
- Verwijder de afdekplaat van het apparaat niet.
- Duw niets door de ventilatieopeningen in het apparaat.
- Hanteer het netsnoer in geen geval met natte handen.
- Bedek de ventilatieopeningen niet met enige voorwerpen, zoals tafelkleden, kranten, gordijnen, enz.
- Plaats geen brandende voorwerpen, zoals kaarsen, op het apparaat.
- Volg bij het weggooien van verbruikte batterijen de overheidswetgeving of milieuvoorschriften op die van kracht zijn in het land of de regio waarin u zich bevindt.
- Zorg dat er 0,1 meter vrije ruimte rond het toestel is.
- Plaats geen voorwerpen met een vloeistof erin, zoals een bloemenvaas, op het apparaat.
- Als de schakelaar op OFF staat, is het apparaat niet volledig losgekoppeld van de netspanning (MAINS).

Downloaded From Disc-Player.com Marantz Manuals

Español

ADVERTENCIAS

- No exponga el equipo a la lluvia ni a la humedad.
- No extraiga la tapa del equipo.
- No introduzca nada en el interior del equipo a través de los orificios de ventilación.
- No maneje el cable de la alimentación con las manos mojadas.
- No cubra la ventilación con objetos como manteles, periódicos, cortinas, etc.
- No deben colocarse sobre el equipo elementos con fuego, por ejemplo velas encendidas.
- Cuando se eliminen baterías usadas, deben cumplirse las reglamentaciones oficiales o las normas de protección medioambiental aplicables en su país o en su zona.
- Deje un espacio de unos 0,1 metro alrededor de la unidad.
- No se deben colocar sobre el aparato recipientes que contengan líquidos, como por ejemplo jarrones.
- Cuando el interruptor está en la posición OFF, el equipo no está completamente desconectado de la alimentación MAINS.

Italiano

AVVERTENZE

- Non esporre l'apparecchio alla pioggia o all'umidità.
- Non rimuovere il coperchio dell'apparecchio.
- Non introdurre oggetti all'interno dell'apparecchio attraverso i fori di ventilazione.
- Non toccare il cavo di alimentazione con le mani bagnate.
- Non coprire le fessure di ventilazione con tovaglie, giornali, tende od oggetti analoghi.
- Non posare sull'apparecchio sorgenti di fiamme scoperte quali candele accese.
- Smaltire le pile usate in conformità alle norme governative o disposizioni ambientali vigenti nel proprio paese o zona.
- Lasciare 0,1 metro liberi tutto intorno l'unità.
- Non mettere sull'apparecchiatura alcun contenitore di liquido, come ad esempio dei vasi.
- Quando l'interruttore è nella posizione OFF, l'apparecchiatura non è completamente scollegata da MAINS.

Svenska

VARNINGAR

- Utsätt inte utrustningen för regn eller fukt.
- Ta inte bort utrustningens hölje.
- För inte in föremål i utrustningen genom ventilationshålen.
- Hantera inte nätkabeln med våta händer.
- Täck inte för ventilationsöppningarna med några föremål som till exempel bordsdukar, dagstidningar, gardiner e.d.
- Inga föremål med öppen låga, som till exempel tända stearinljus, bör placeras på utrustningen.
- Följ de lagar och miljöskyddsråd som gäller i det land eller område där du bor när du gör dig av med batterier.
- Se till att det finns omkring 0,1 meter fri plats runt omkring enheten.
- Inga objekt som är fyllda med någon vätska, till exempel blomstervaser, bör placeras på apparaten.
- Även om strömbrytaren står i det avstängda läget OFF, så är utrustningen inte helt bortkopplad från det elektriska nätet (MAINS).

Downloaded From Disc-Player.com Marantz Manuals

ENGLISH

FOREWORD

This section must be read before any connection is made to the mains supply.

EQUIPMENT MAINS WORKING SETTING

Your Marantz product complies with the household power and safety requirements in your area.
This product can be powered by 230 V AC only.

COPYRIGHT

Recording and playback of any material may require consent. For further information refer to the following:

— Copyright Act 1956

— Dramatic and Musical Performers Act 1958

— Performers Protection Acts 1963 and 1972

— any subsequent statutory enactments and orders

A NOTE ABOUT RECYCLING

This product's packaging materials are recyclable and can be reused. This product and the accessories packed together are the applicable product to the WEEE directive except batteries.
Please dispose of any materials in accordance with your local recycling regulations.
When discarding the unit, comply with your local rules or regulations.
Batteries should never be thrown away or incinerated but disposed of in accordance with your local regulations concerning chemical wastes.

INTRODUCTION

Thank you for selecting the Marantz CD5001 CD Player for your A / V system.
This Compact Disc Player incorporates a number of features designed to enhance the listening of your favorite audio sources.
Please read these operating instructions carefully. We recommend that you read the entire user guide before you attempt to connect or operate the player.
After you have reviewed the contents of this manual,we suggest that you make all system connections before you attempt to operate the unit.

INSTALLATION

Remember the following important points when installing the player:

- Do not expose the player to rain or moisture, as this may cause damage to the player.
- All players produce some heat during operation and this heat must be allowed to disperes freely. Do not close any ventilation openings and insure that there is adequate ventilation space behind, beside and above the player.
- Prevent extra heat from reaching the unit. Never put the player in the full glare of the sun or near a heat source.

PRECAUTIONS

The following precautions should be taken when operating the equipment.

GENERAL PRECAUTIONS

When installing the equipment ensure that:

– the ventilation holes are not covered.

– air is allowed to circulate freely around the equipment.

– it is placed on a vibration-free surface.

– it will not be exposed to excessive heat, cold, moisture or dust.

– it will not be exposed to direct sunlight.

– it will not be exposed to electrostatic discharges.

In addition, never place heavy objects on the equipment.
If a foreign object or water does enter the equipment, contact your nearest dealer or service center.
Do not pull out the plug by pulling on the mains lead; grasp the plug.
It is advisable when leaving the house for an extended period, or during a thunderstorm, to disconnect the equipment from the mains supply.

PRECAUTIONS IN CONNECTION

- Be sure to unplug the power cable from the AC outlet or turn off the POWER switch before proceeding with any connection.
- Connect one cable at a time observing the "input" and "output". This will avoid any cross connection between channels and signal inputs and outputs.
- Insert the plugs securely. Incomplete connection may result in noise.
- Prior to connecting other audio equipment to the CD5001, please read their owner's manuals.

Downloaded From Disc-Player.com Marantz Manuals

CONTENTS

ENGLISH

1. BEFORE USING 3
2. ACCESSORIES 5
3. FEATURES 6
4. CONNECTIONS 7
5. NAMES AND FUNCTIONS 8
   - Front panel 8
   - Display 9
   - Remote control unit 10
   - Rear panel 11
6. BASIC OPERATIONS 12
   - Playing CDs 12
   - Playing a specific track 13
   - Playing a specific part of a specific track 14
7. ADVANCED OPERATIONS 15
   - Repeat play (playing the same tracks repeatedly) 15
   - Random play (playing tracks in a random sequence) 16
   - AMS play (searching for a specific track) 16
   - Program play (playing tracks in the preferred sequence) 17
   - Delete program play (play with undesired tracks skipped) 19
   - Peak search (searching for the loudest passage) 22
   - Editing (recording a disc on a tape) 22
   - Pitch control (changing the play speed) 25
8. OTHER FUNCTIONS 26
   - CD-TEXT 26
9. SPECIFICATIONS AND DIMENSIONS 27
   - Specifications 27
   - Dimensions (unit: mm) 27
10. TROUBLESHOOTING 28

Downloaded From Disc-Player.com Marantz Manuals

ENGLISH

Notes about the discs

*** Handle the discs carefully so as not to scratch their surfaces.**

*** Keep the surfaces of the discs clean at all times.**

When cleaning the surfaces of discs, always be sure to use the special cleaner and wipe the surfaces in the directions shown in the figure below.





- Wipe the surface radially from the center.
- Do not wipe the surface in the circumferential direction.

*** Do not attach pieces of paper or stickers to the label surfaces of the discs.**

When a disc has a piece of plastic tape or rental CD label with paste protruding from the edge or when a disc still bears traces of sticky tape or adhesive labels, do not attempt to play it. If such a disc is played on the CD player, you may find that you cannot remove it or that some other kind of malfunctioning may occur.



*** Do not use discs which come in special shapes.**

Do not attempt to play heart-shaped or octagonal discs or discs with any other special shapes. You may find that you cannot remove them or that some other kind of malfunctioning may occur in the player.



*** Use discs which satisfy the CD standards such as those with the "CD logo", "COMPACT disc DIGITAL AUDIO" or "COMPACT disc DIGITAL AUDIO TEXT" mark on their disc label surfaces.**

No guarantees are made for playback if discs which do not satisfy the appropriate CD standards are used.
Similarly, no guarantees are made for their sound quality even if it is possible to play such discs.

*** To protect your discs from damage, avoid placing them in the following locations.**

- Where they will be exposed to direct sunlight or where they will be close to a heater or other heat-radiating appliance
- Where the humidity level is high or it is very dusty
- Near a window or other such location where they may be exposed to rain

*** Get into the habit of putting the discs back in their cases after use.**

Inappropriate places for installation

To keep your player in perfect working order for the longest possible time, avoid installing the player in the following locations.

- Wherever it will be exposed to direct sunlight
- Wherever it will be close to a heater or other heat-radiating appliance
- Wherever the humidity is high or ventilation is poor
- Wherever it is very dusty
- Wherever it will be subject to vibration
- On top of a rickety stand or in an unstable location which is tilted at an angle
- On top of an amplifier or other component which dissipates a great deal of heat
- In an audio rack with little space at the top and bottom or other location where the heat dissipation will be obstructed To ensure proper heat dissipation, install the player while leaving clearances between the player and wall or other components, as shown in the figure below.



About playing copy-controlled CDs

Some copy-controlled CDs may not conform to official CD standards. They are special discs and may not play on the CD5001.

Downloaded From Disc-Player.com Marantz Manuals

ENGLISH

Do not place objects on top

- Refrain from placing any objects on top of the player.

Cautions on handling mains cord

- Do not touch the mains cord with wet hands.
- When disconnecting the mains cord, always make sure that you take hold of the plug. Yanking out or bending the cord can damage it and/or cause electric shocks or a fire.
- Get into the habit of disconnecting the power plug before leaving home.

Do not attempt repairs yourself

- Refrain from lubricating the player: doing so can cause malfunctioning.
- Only qualified engineers with specialized expertise are authorized to repair the pick-up and parts inside the player.

Precautions

- In winter, droplets of water form on the insides of the windows of a heated room: this is called condensation. This CD player uses an optical lens, so the condensation may form in the following cases.
  - In a room immediately after the heating has been turned on
  - In a room where the humidity level is high
  - When the player has been suddenly brought from a cold location into a warm room

  Since, in cases like this, the track numbers may not be read and the player is prevented from operating properly, wait about 30 minutes, and then operate the player.
- This player may cause interference on a tuner or TV set. If this is the case, place it further away from the tuner or TV set.
- Compact discs have much less noise than analog records and hardly any noise is heard before play starts. Bear in mind, therefore, that if the volume control on the amplifier is set too high, you will risk damaging other audio components.
- This player is designed to play music CDs only. It cannot play CD-ROMs used with personal computers, game CDs, video CDs or DVDs (video/audio).

Cautions on handling batteries

Misuse of the batteries can result in electrolyte leakage, rupturing, corrosion, etc.

Bear in mind the following points when using batteries.

- Remove the batteries from the remote control unit if the unit is not going to be used for a prolonged period (a month or more).
- Do not use an old battery together with a new one.
- Insert the batteries while ensuring that their ⊕ and ⊖ poles are properly aligned with the corresponding markings on the remote control unit.
- Batteries with the same shape may have different voltages. Do not use different types of batteries together.
- If electrolyte has leaked, thoroughly wipe the inside of the battery compartment, and then insert new batteries.

Downloaded From Disc-Player.com Marantz Manuals

2. ACCESSORIES

Checking the accessories

After opening the cover of the packing box, check that the following accessories are included.

- **Remote control unit (RC5400CD)**



- **Size "AAA" batteries x 2**



- **Audio connecting cord**



- **Remote control connecting cord**



- **User Guide**
- **Registration Card**

Usage of REMOTE CONTROL UNIT

• Precautions

- Do not allow direct sunlight, an inverter fluorescent light or other strong source of light to shine onto the player's infrared signal reception window (remote sensor). Otherwise, the operation of the remote control unit may be disabled.
- Bear in mind that operating the remote control unit may cause other devices operated by infrared rays to be operated by mistake.
- The remote control unit cannot be operated if the space between the controller and the player's remote sensor is obstructed.
- Do not place any objects on top of the remote control unit. Doing so may cause one or more buttons to be held down which will cause the batteries to run down.

• Operational range

As shown in the figure below, the player can be operated by the remote control unit in a range which of about 5 meters from the player's remote sensor and over an angle up to 30 degrees to the left and 30 degrees to the right of the position directly in front.



• Loading batteries

Before using the supplied remote control unit for the first time, load the batteries in the remote control unit. The batteries provided are used to verify the operations of the remote control unit only.

1 Take hold of the tab on the battery cover which is found on the back side of the remote control unit, and pull it up.



2 Load the two new size "AAA" batteries inside the battery compartment while taking care to align their polarities correctly with the polarity markings (⊕ with ⊕ and ⊖ with ⊖).

Size "AAA" (SUM-4) batteries x 2



3 Push the battery cover down in the direction of the arrow to close it.



Downloaded From Disc-Player.com Marantz Manuals

3. FEATURES

ENGLISH

- **CS4392 high-performance D/A converter made by Cirrus Logic used**

  The CS4392 D/A converter whose CD playback circuitry has the same design as the CS4396 D/A converter, which was also made by Cirrus Logic and which has proved to be a valuable asset for the Marantz CD player, has been adopted.
  During CD play, the PCM signals recorded on the disc are oversampled to 128fs inside the D/A converter and then processed by a combination of the dynamic element matching (DEM) and multi-element switched capacitors to achieve playback characterized by a high linearity.
  This new CD playback technology opens the door to new dimensions in high-sound-quality CD play.

- **Display OFF function incorporated**

  The “display OFF” function enables the main unit display to be turned off. By turning off this display, the pulsive noise generated from the display is reduced, thus eliminating its effects on the music signals.

- **Pitch control function**

  The “pitch control” function enables the play speed (pitch) to be varied over a ±12 step. This feature is particularly useful for musical instrument practice sessions.

- **Quick replay function**

  By a single-action operation, the “quick replay” function enables play to be moved back from the current play position for 10 seconds and play to be resumed.
  This function makes it possible to return to a part of the track that was just played so it can be heard again.

- **CD-TEXT display supported**

Downloaded From Disc-Player.com Marantz Manuals

4. CONNECTIONS

ENGLISH

This CD player is connected to an amplifier, CD recorder and other components for use. To ensure that the components are connected properly, refer to the instruction manuals that come with the components to be connected.
Before connecting the components, be absolutely sure to turn off their power.

Connecting to an amplifier

Use the audio connecting cord to connect the player with a stereo amplifier or AV amplifier. Do not connect the player to the PHONO input connectors on the amplifier.
When making the connections, insert the plugs securely into the connectors. Failure to insert the plugs securely may result in noise.



Amplifier

Connecting to a digital audio component

The player has one digital optical output connector and one digital coaxial output connector.
You can enjoy digital recording when the player is connected to a CD recorder or other digital recording component.

• Connecting the optical output connector

Use an optical digital connecting cable available on the market. Insert the plug firmly in until it clicks into place. Do not bend or bundle the optical digital connecting cable.



CD recorder, MD deck, AV amplifier, etc.

• Connecting the coaxial output connector

Use a coaxial digital connecting cable available on the market.



CD recorder, MD deck, AV amplifier, etc.

Downloaded From Disc-Player.com Marantz Manuals

5. NAMES AND FUNCTIONS

ENGLISH

Front panel



1 POWER ON/STANDBY switch and Standby indicator

This is used to turn the player's power ON and STANDBY. When it is pressed, the display lights and the power is turned on; when it is pressed again, the power is turned off and STANDBY indicator lights.

2 Disc tray

This is where the CD to be played is placed.

3 OPEN/CLOSE ⏏ button

This is used to open and close the disc tray. When it is pressed, the disc tray opens; when it is pressed again, it closes.

4 Remote sensor

This senses the infrared control signals sent from the remote control unit.

5 DISPLAY OFF indicator

This lights in the DISPLAY OFF mode (when the display is off).

6 Display

This shows the settings, play status, text information, etc.

7 TIME button

Switches the time shown on the display to the remaining time of the current track or the remaining time of the entire disc.

With a CD-TEXT disc, this switch is also used to switch the displayed information from the text display mode to the time display mode.

8 EDIT button

Press to engage the editing function, which helps record a disc onto a tape by playing the tracks according to the tape length and leaving a nonrecorded blank of 4 seconds between every track.

9 PEAK button

When the PEAK button is pressed, searching for the loudest passage (peak) on a CD or in a program.

10 DISPLAY OFF button

This is used to turn off the display (DISPLAY OFF mode). When it is pressed, the display is turned off; when it is pressed again, the display comes on.

11 PLAY ► button

This is used to start play.

12 STOP ■ button

This is used to stop play.

13 PAUSE ⏸ button

This is used to temporarily suspend play.

14 ⏮/◄◄ (previous track/search backward) button

When this button is pressed, play returns to the start of the track now being played. The same number of tracks as the number of times the button is pressed can be skipped in the reverse direction. When the button is held down, tracks are searched (fast backward).

15 ►►/⏭ (search forward/next track) button

The same number of tracks as the number of times the button is pressed are skipped in the forward direction. When the button is held down, tracks are searched (fast forward).

16 PHONES jack

The headphones are connected to this jack. Use headphones that come with a standard plug.

17 PHONES LEVEL control

This is used to adjust the headphones volume level. The level increases when it is turned clockwise.

Downloaded From Disc-Player.com Marantz Manuals

ENGLISH

Display



ⓐ Main display
This displays the time information and text information of the disc played, the setting menus, etc.

ⓑ TEXT indicator
This lights when a disc supporting CD-TEXT has been loaded.

ⓒ ❚❚ (pause) indicator
This lights when play is temporarily suspended.

ⓓ ► (play) indicator
This lights during play.

ⓔ DISC indicator
This flashes during readout of the table of contents (TOC) information on the disc.

ⓕ TTL (total track) indicator
This lights above the display of the total number of tracks recorded on the disc.

ⓖ RNDM (random) indicator
This lights during random play.

ⓗ TRK (track) indicator
This lights above the display of the number of the track being played, etc.

ⓘ PROG (program) indicator
This lights during program play.

ⓙ A-B (A-B repeat) indicator
This lights during A-B repeat play.

ⓚ RPT (repeat) indicator
This lights during repeat play.

ⓛ 1 (1-track repeat) indicator
This lights during 1-track repeat play.

ⓜ PITCH (pitch control) indicator
Lights up when the pitch control function is set and active.

ⓝ EDIT indicator
This lights during edit mode.

ⓞ PEAK indicator
This lights during peak search and playback of the peak.

ⓟ TTL (total time) indicator
When the total remaining time or total program time is displayed, this lights above that display.

ⓠ TIME indicator
This lights while the elapsed time or other such time is displayed.

ⓡ 1 - 20, ⌐ (music calendar)
This displays the track numbers recorded on the disc, the track numbers still to be played, and the track numbers programmed for program play.

Downloaded From Disc-Player.com Marantz Manuals

ENGLISH

Remote control unit



① DISPLAY button
This is used to turn off the display (DISPLAY OFF mode).

② Numeric buttons (0 to 9)
These are used to specify the numbers of the tracks to be played.

③ PROGRAM button
This is pressed to initiate program play.

④ RANDOM button
This is used to play the tracks in a random sequence.

⑤ ► (play) button
This is used to start play.

⑥ II (pause) button
This is used to temporarily suspend play.

⑦ ■ (stop) button
This is used to stop the play.

⑧ ◄◄, ►► (search) buttons
◄◄ : This button is used to search backward when it is held down during play.

►► : This button is used to search forward when it is held down during play.

⑨ PITCH -/RESET/+ (pitch control down/reset/up) buttons
These are used to adjust the play speed (pitch) with a ±12 step.

⑩ AMS (auto music scan) button
This is used to play the intros of all the tracks in sequence starting from the first track for the duration equivalent to the setting.

⑪ TEXT button
This is used to switch the main display from the time display to the text display.

⑫ POWER button
This is used to switch the player's power ON and STANDBY.

⑬ CANCEL button
This is used to cancel the programmed tracks.

⑭ QUICK REPLAY button
Press the button to return to the position 10 seconds before the current playback position and restarts playback from there.

⑮ ⏮, ⏭ (track skip) buttons
⏮ : Use this to return to the start of the track now playing or return to the start of the previous track.

⏭ : Use this to advance to the start of the subsequent track.

⑯ REPEAT button
This is used to play one track or all the tracks on the disc repeatedly.

⑰ A-B (A-B repeat) button
This is used to set start point (A) and end point (B) when a particular section is to be played repeatedly.

⑱ TIME button
This switches the main display from the text display to the time display. It can also switch the time display during play. It can display how much time has elapsed and how much play time remains for the current track as well as how much play time remains for the whole disc.

⑲ SCROLL/RECALL button
This is used to scroll the text display when text is displayed. When it is pressed during program play, it is possible to check which tracks have been programmed.

Downloaded From Disc-Player.com Marantz Manuals

Rear panel



Ⓐ ANALOG OUT (analog output) connectors

The music signals during play are output from these connectors.

Ⓑ DIGITAL OUT COAX. (digital coaxial output) connector

The music signals during play are output digitally from this coaxial output connector.

* Digital signals are not output during pitch control play.

Ⓒ DIGITAL OUT OPT. (digital optical output) connector

The music signals during play are output digitally from this optical output connector.

* Digital signals are not output during pitch control play.

Ⓓ REMOTE CONTROL IN and OUT connectors

Using the supplied remote control connecting cable, these connectors enable this player to be connected to a Marantz component equipped with remote control connectors. These connections make it possible to control an entire system that centers on the amplifier or other such component.

Ⓔ EXTERNAL/INTERNAL switch

Before the player was shipped from the factory, this switch was set to INTERNAL to enable the remote sensor built into the player to be used.

Before using the supplied connecting cable to make the connection between the player and the remote control connectors on a Marantz equipment, set the switch to EXTERNAL.

Note:

Signals cannot be received from the remote control unit if the switch is kept at EXTERNAL when the player is to be used on its own.

Ⓕ MAINS CONNECTION

Plug the mains cord into a mains outlet providing the right voltage.

Downloaded From Disc-Player.com Marantz Manuals

ENGLISH

Playing CDs





1. Turn on the power of the amplifier to which the player is connected, and use the input selector on the amplifier to select "CD" (the player's input source which has been connected).

2. Press the POWER button on the player to turn on the power.

3. Press the OPEN/CLOSE ⏏ button on the player. Place the CD to be played in the extended disc tray while ensuring that the label with the printed text is facing up.



In the case of a single (8 cm) CD, align it with the indentation in the center of the tray.

4. Press the OPEN/CLOSE ⏏ button on the player to retract the disc tray. Pushing the front of the disc tray lightly also causes the tray to be retracted. Once the disc tray has been retracted, "TOC Reading" appears on the display, after which the total number of CD tracks and total playing time are displayed. In the case of a disc that supports CD-TEXT, the album title is displayed, and then the total number of CD tracks and total playing time are displayed.

5. Press the ► button on the player or remote control unit to start play. Adjust the volume level at the amplifier.

• Stopping play



Press the ■ button on the player or remote control unit during play.

• Pausing play



During play, press the ❚❚ button on the player or remote control unit to temporarily suspend play.
To resume play from the place where it was temporarily suspended, press the ► button or ❚❚ button on the player or the ► button or ❚❚ button on the remote control unit.

Caution:

When the tray is opened by pressing the disc tray OPEN/ CLOSE ⏏ button, the try will close automatically in 30 seconds.
When placing a disc, be careful not to have your finger caught by the disc tray or have the disc damaged.

• Removing the CD



After play has finished, press the OPEN/CLOSE ⏏ button on the player to extend the disc tray, and remove the CD.
After the CD has been removed, press the OPEN/CLOSE ⏏ button again to retract the disc tray. The disc tray should always be retracted when the player is not in use.

Downloaded From Disc-Player.com Marantz Manuals

Playing a specific track

• Specifying the number of a track to be played (direct search)

Select the number of the track to be played directly by pressing the numeric buttons (0 to 9) on the remote control unit.
To select track number 10 or above, use the numeric buttons to select the higher digit first and then select the lower digit.
Once the number of the track is selected, play will start automatically.

Example: To play track 3
Press the "3" numeric button.



Example: To play track 12
Press the "1" numeric button.



Within 1.5 second, press the "2" numeric button.



• Playing a previous or subsequent track (track skip)

Advancing to a subsequent track



Press the ►►/►►I button on the player or ►►I button on the remote control unit for the number of times equivalent to the number of tracks through which play is to be advanced.

Returning to the start of the track now playing or a previous track



When the I◄◄/◄◄ button on the player or I◄◄ button on the remote control unit is pressed, play returns to the start of the track now playing. Play returns to the previous track which is equivalent to the number of times the button was pressed.

Downloaded From Disc-Player.com Marantz Manuals

ENGLISH

Playing a specific part of a specific track

• Searching a specific part of a track (search)

While listening to a track being played, it is possible to search a specific part of that track by a forward or backward search.

Forward searching through the track now playing



The search (forward search) mode is established by holding down the ►►/►►I button on the player or ►► button on the remote control unit.
Holding down the button initiates a forward search.

Backward searching through the track now playing



The search (backward search) mode is established by holding down the I◄◄/◄◄ button on the player or ◄◄ button on the remote control unit.
Holding down the button initiates a backward search. (Returns during backward searches are not constant.)

• Playing the last 10 seconds again during play (quick replay)



When the QUICK REPLAY button on the remote control unit is pressed during play, play will be returned by 10 seconds, and the same section will be played again.

Downloaded From Disc-Player.com Marantz Manuals

ENGLISH

Repeat play (playing the same tracks repeatedly)

• Playing all tracks repeatedly (all-track repeat)

This function repeatedly plays all the tracks. Repeat play is possible even during random play or program play.

Press the REPEAT button on the remote control unit.



The “RPT” indicator on the display lights, and the repeat play of all the tracks starts.



To stop all-track repeat play and resume normal play, press the REPEAT button on the remote control unit twice. The “RPT” indicator on the display goes off.

• Playing one track repeatedly (1-track repeat)

This function repeatedly plays one track only. Even during random play or program play, it repeats the track being played. Press the REPEAT button on the remote control unit twice while the track to be repeated is playing.



The “RPT” and “1” indicators light, and track now playing is repeated.



To stop 1-track repeat play and resume normal play, press the REPEAT button on the remote control unit to turn off the “RPT” indicator on the display.

• Playing a specific part repeatedly (A-B repeat)

This function repeatedly plays a specific part of a track that you want to hear.

1. During play, press the A-B button on the remote control unit at the start point of the part to be repeated.



The “A-” indicator on the display now lights.

Display example: A-B repeat , point A (start), track 1, 5 sec.



2. Press the A-B button on the remote control unit at the end point of the part to be repeated.



The “A-B” indicator on the display now lights, and the designated part (from point A to point B) is played repeatedly.

Display example: A-B repeat , point B (end), track 1, 20 sec.



To stop A-B repeat play and resume normal play, press the A-B button on the remote control unit to turn off the “A-B” indicator on the display.

Note:

The A-B repeat play function cannot be used during random play.

Downloaded From Disc-Player.com Marantz Manuals

ENGLISH

Random play (playing tracks in a random sequence)

This function rearranges the tracks into a random sequence and it then plays all the tracks in this random sequence. If it is used together with repeat play, the same tracks can be repeatedly played but in a different sequence every time.

During play or stop, press the RANDOM button on the remote control unit.



The items on the music calendar appear on the display one after the other, and the “RNDM” indicator lights.



Random play now starts.



To stop random play and resume normal play, press the RANDOM button on the remote control unit. The “RNDM” indicator on the display goes off.

• Skipping tracks during random play to search other tracks

When the ►►/►►I button on the player or ►►I button on the remote control unit is pressed during random play, the next track is selected at random and played.
Conversely, when the I◄◄/◄◄ button on the player or I◄◄ button on the remote control unit is pressed during random play, play returns to the start of the track now playing.

AMS play (searching for a specific track)

This function comes in handy when searching for a specific track that you want to hear.
You can choose whether to play 10, 20 or 30 seconds of each track.

During stop or play, press the AMS (auto music scan) button on the remote control unit.



Press the AMS button repeatedly to switch through the different scan modes.
“Scan 10”, “Scan 20”, “Scan 30”, “Scan Off”... (Scan Off aborts the scan function) light on the display, and the “►” indicator flashes.



The intros of all the tracks starting from track 1 are played in succession for the duration which has been select.



Once the track you want to hear has been found, press the ► button. The “►” indicator now lights, and the track found and whatever comes after that track will now be played normally.
When the RANDOM button on the remote control unit is pressed during AMS play, the AMS play function is released, and the random play mode is established.

Downloaded From Disc-Player.com Marantz Manuals

Program play (playing tracks in the preferred sequence)

The order in which the CD tracks are played can be rearranged into the sequence desired. Up to 30 tracks can be programmed.

• Program play in the time display mode

In the case of a CD-TEXT disc, first press the TIME button on the remote control unit to set the main display to the time display mode.





1. During stop, press the PROGRAM button on the remote control unit.



"Program" appears for an instant on the main display.

Flashes



The PROG indicator flashes, and the program mode is established.

Flashes



2. Press the numeric buttons on the remote control unit the tracks can also be selected using the ⏮ and ⏭ buttons on the remote control unit or ⏮/◀◀ and ▶▶/⏭ buttons on the player. To select track number 10 or above, use the numeric buttons to select the higher digit first and then select the lower digit.



Display example: When track 2 has been selected

Flashes



3. Repeat step 2 to program the desired tracks in sequence. At each step of the programming, the number of tracks programmed and their total time appear on the main display. Up to 30 tracks can be programmed.

Flashes



4. Once all the tracks have been programmed, press the ■ button on the player or remote control unit or press the PROGRAM button on the remote control unit.



The PROG indicator stops flashing and lights up instead, and the program is entered.

Light up



5. Press the ▶ button on the player or remote control unit. Play now starts in the programmed sequence.
Program play will start even when step 4 is omitted.

Downloaded From Disc-Player.com Marantz Manuals

ENGLISH

• Program play in the text display mode

In the case of a CD-TEXT disc, tracks can be selected by title for program play.

If the main display is set to the time display mode, press the TEXT button on the remote control unit to establish the text display mode.



1. During stop, press the PROGRAM button on the remote control unit.



"Program" appears for an instant on the main display. Then the PROG indicator flashes, and the program mode is established.



2. Press the ⏮ and ⏭ buttons on the remote control unit or ⏮/◀◀ and ▶▶/⏭ buttons on the player to select the track. (The track can also be selected using the numeric buttons on the remote control unit but in this case the title is not displayed).



The title of each selected track is scrolled, and once it has been scrolled, it is programmed automatically. If you do not want to program the track, select another track before the scrolling is completed.



3. Repeat step 2 to program the desired tracks in sequence. Up to 30 tracks can be programmed.

4. Once all the tracks have been programmed, press the ■ button on the player or remote control unit or press the PROGRAM button on the remote control unit.



The PROG indicator stops flashing and lights up instead, and the program is entered.



5. Press the ▶ button on the player or remote control unit. Play of the selected tracks now starts in the programmed sequence.
Program play will start even when step 4 is omitted.

Note:

Programming in the text display mode cannot be performed for tracks which have no text information for their titles.

Downloaded From Disc-Player.com Marantz Manuals

Delete program play (play with undesired tracks skipped)

This function makes it possible to skip those tracks that you do not want to hear during CD play. Up to 30 tracks can be deleted from the program.

• Delete program play in the time display mode

In the case of a CD-TEXT disc, first press the TIME button on the remote control unit to set the main display to the time display mode.





1. During stop, press the PROGRAM button on the remote control unit, and then press the CANCEL button.



"Delete Prog." appears for an instant on the main display.



The total number of CD tracks and the total play time appear on the main display, the PROG indicator flashes, and the delete program mode is established.



2. Press the numeric buttons on the remote control unit that you do not want to hear (the track can also be selected using the ⏮ and ⏭ buttons on the remote control unit or ⏮/◀◀ and ▶▶/⏭ buttons on the player).



Display example: When track 2 has been selected



3. Repeat step 2, and upon completion of the programming, press the ■ button on the player or remote control unit or press the PROGRAM button on the remote control unit.



The PROG indicator in the display stops flashing and lights up instead, and the delete program is entered. Up to 30 tracks can be deleted from the program.



4. Press the ► button on the player or remote control unit. The CD is now played but with the deleted tracks skipped.

Downloaded From Disc-Player.com Marantz Manuals

ENGLISH

• Delete program play in the text display mode

In the case of a CD-TEXT disc, the tracks that are not desired can be selected by title for delete program play.

If the main display is set to the time display mode, press the TEXT button on the remote control unit to establish the text display mode.



1. During stop, press the PROGRAM button on the remote control unit, and then press the CANCEL button.



"Delete Prog." appears for an instant on the main display.



The total number of CD tracks and the total playing time appear on the main display, the PROG indicator flashes, and the delete program mode is established.



2. Press the ⏮ and ⏭ buttons on the remote control unit or ⏮/◀◀ and ▶▶/⏭ buttons on the player to select the track which you do not want to hear. (The tracks can also be selected using the numeric buttons on the remote control unit but in this case the titles will not be displayed.)



The title of each selected track is scrolled, and once it has been scrolled, it is deleted automatically. If you do not want to delete the track, select another track before the scrolling is completed.



3. Repeat step 2, and upon completion of the programming, press the ■ button on the player or remote control unit or press the PROGRAM button on the remote control unit.



The PROG indicator in the display stops flashing and lights up instead, and the delete program is entered. Up to 30 tracks can be deleted from the program.



4. Press the ▶ button on the player or remote control unit. The CD is now played but with the deleted tracks skipped.

Note:

Delete programming in the text display mode cannot be performed for tracks which have no text information for their titles.

Downloaded From Disc-Player.com Marantz Manuals

• Checking the program or delete program contents



During programming operation or program play, press the SCROLL/RECALL button on the remote control unit.
With program play, the programmed tracks are displayed one after the other in sequence on the main display.
With delete program play, the deleted tracks are displayed one after the other in sequence on the main display.

• Changing the program or delete program contents



Deleting tracks which were programmed for program play

When the SCROLL/RECALL button on the remote control unit is pressed during programming, the programmed tracks are displayed one after the other in sequence.
As soon as the track to be deleted from the program has appeared, press the CANCEL button on the remote control unit immediately. The number of the deleted track is cleared from the music calendar on the display.

Canceling the deletion of tracks which were deleted for delete program play

When the SCROLL/RECALL button on the remote control unit is pressed during delete programming, the deleted tracks are displayed one after the other in sequence.
As soon as the track whose deletion is to be canceled has appeared, press the CANCEL button on the remote control unit immediately. The number of the track whose deletion was canceled is displayed in the music calendar on the display.

• Returning program play to normal play (canceling the entire program)



Press the ■ button on the player or remote control unit twice during program play or once during stop. The PROG indicator on the display goes off, and the entire program is canceled.



Alternatively, a program can be canceled when the disc tray is opened by pressing the OPEN/CLOSE ⏏ button on the player.

Adding tracks to the program



Press the PROGRAM button on the remote control unit during stop. The status of the PROG indicator in the display changes from lighted to flashing, and more tracks can be added to the program.

• Precautions for program and delete program play

* When using the numeric buttons to select tracks 1 to 9 on a CD with 10 or more tracks in total, allow 1.5 seconds or so to elapse after the button corresponding to the number of the previous track was pressed before pressing the button corresponding to the number of the next track.
* When using the numeric buttons to select track 10 or up on a CD with 10 or more tracks in total, press the button corresponding to lower digit within 1.5 seconds or so after the button corresponding to the higher digit was pressed.
* When using the ⏮ and ⏭ buttons for programming, keep pressing one of these buttons with less than half a second or so in between until the number of the desired track is displayed.
* If the total time for a program exceeds 99 minutes 59 seconds, the time display will appear as "– – : – –".

Downloaded From Disc-Player.com Marantz Manuals

ENGLISH

Peak search (searching for the loudest passage)

If the cassette deck recording level is adjusted in relation to the peak level on the disc, it is possible to avoid distortion and noise in recording. This facility allows the peak over the entire disc or in the programmed to be detected tracks before proceeding to editing.

1. Press the PEAK button on the player. "PEAK" will light up and the peak search operation will begin from the first passage on the disc. Searching may need a few minutes.



2. When peak search of the last passage is completed, play will be repeated for approximately 6 seconds with the volume at a comparatively high level. Adjust the record level of the cassette deck. (Please see the instruction manual for the cassette deck.)



3. Press the ■ button on the player or remote control unit to stop the peak search operation.

Note:

As a CD may contain several peaks, a different peak may be found every time the auto peak level search operation is performed.

Editing (recording a disc on a tape)

When recording from a compact disc to a tape, use this function to match the tape length to the playing time of the tracks to be recorded and to create 4-second intervals between the tracks.

• Simple edit

This operation fits tracks into a specified tape length while keeping the tracks in their original order.

1. Press the EDIT button in stop mode to light up the EDIT indicator. (Example: When a disc with 28 tracks is loaded)


Light up
EDIT
Edit
TEXT 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20
Flashes
Light up
EDIT
Last track on tape side B
Last track on tape side A
The tape recording time display (90) appears.

This example shows that, when the tape recording time is 90 minutes, track 15 is the last track on tape side A and track 28 the last track on tape side B. In other words, by using a 90-minute tape, all of the 28 disc tracks can be accommodated by assigning tracks 1 to 15 on tape side A and tracks 16 to 28 on tape side B.

2. To change the tape recording time, specify the new tape recording time using the ►►I or I◄◄ button or the numeric buttons (0 to 9).

• Use of ►►I and I◄◄ buttons

Each press of the ►►I button allows you to change the recording time in the order 90 → 46 → 54 → 60 → 74 → 90.
Each press of the I◄◄ button allows you to change the recording time in the order 90 → 74 → 60 → 54 → 46 → 90.
Each press of the ►► button allows you to increase the recording time by 1 minute.
Each press of the ◄◄ button allows to decrease the recording time by 1 minute.

• When numeric buttons are used to specify a C-46 tape, for example, press 4 then 6.



This display example shows that, with a 46-minute tape, tracks 1 to 8 will be recorded onto tape side A and tracks 9 to 16 will be recorded onto tape side B.
The blinking arrow on the right end of the character display shows that tracks 17 and after cannot be recorded on the tape.

3. Press the EDIT button again and set the editing contents.


Light up
Light up
TTL
TRK
A
EDIT
TTL
TIME
TEXT 1 2 3 4 5 6 7 8 9 10 11 12 13 14 15
Total playing time of side A
Number indicators of tracks assigned to side A light up.
Total number of tracks on side A

4. Perform the play by following the procedure for sync recording.

Downloaded From Disc-Player.com Marantz Manuals

• Program edit

This procedure allows you to record tracks in any desired order while fitting the tracks into a specified tape length.

1. Program tracks according to the programming procedure in section “PROGRAM PLAY” (page 17).
2. The rest of the program edit procedure is the same as step 1 to 3 in the simple edit procedure.

• Delete program edit

When recording from a disc to a tape, this procedure allows you to omit the tracks you do not want to record, while fitting the tracks into a specified tape length.

1. Program tracks according to the “delete programming” procedure in the “PROGRAM PLAY” section (page 19).
2. The rest of the delete program edit procedure is the same as step 1 to 3 in the simple edit procedure.

Note:

- **During the simple edit play, program edit play and delete program edit play, any operations other than the STOP, OPEN/CLOSE and TIME Display OFF buttons are disabled. This is intended to prevent mistakes in recording due to erroneous operation.**
- **While editing, remote control operations are disabled.**
- **The display is always in the time display mode during edit play. It is not possible to switch to the text display mode.**

• Start Edit Recording

Before start editing, connect remote control input of Marantz cassette deck with remote control output of CD5001 by remote control cable.
Reverse mode switch may be set to any of one side (⇄), both sides (⊃) and continuous play (∞).

- Synchro recording with Marantz auto reverse cassette deck set to both sides (⊃) or continuous play (∞) mode.

1. After setting up, setup the cassette deck to rec pause state.

2. Press ► or ❚❚ buttons of the player to start A side program. The player sends out signal to start recording and starts playing A side program after 4 seconds.





3. After A side program complete, player turns to the pause state at the beginning of B side program.



Total number of tracks on side B

Total playing time of side B

Number indicators of tracks assigned to side B light up.

4. When A side of the tape ends up, cassette deck inverts its recording direction and set to rec pause state automatically.

5. Press ► or ❚❚ buttons of the player manually to start B side recording. Player sends out signal to restart recording and starts playing B side program after 4 seconds.



6. After B side program complete, player stops playing and clears edit program automatically.

Note:

- **If the tape ends up before edit program of one side completes, for example by wrong tape length have chosen, cassette deck send out signal to player to let the player cancel the rest of program. Player jumps to the beginning of B side if it was A side or stop playing and clear edit program if it was B side.**
- **Synchro recording can be started only when a Marantz autoreverse cassette deck (ex. SD4050 etc.) with synchro recording compatibility is connected to the CD player.**
- **Synchro recording is performed through the remote line connection (rear panel jacks).**

Downloaded From Disc-Player.com Marantz Manuals

- Synchro recording with Marantz one-way cassette deck, or Marantz auto reverse cassette deck set to one side (⇄) mode.

1. After setting up Edit program, setup the cassette deck to rec pause state.

2. Press ► or ❚❚ buttons of the player to start A side program. The player sends out signal to start recording and starts playing A side program after 4 seconds.



3. After A side program complete, player turns to the pause state at the beginning of B side program.

4. When A side of the tape ends up, Reverse cassette tape or invert recording direction manually and set to rec pause state.

5. Press ► or ❚❚ buttons of the player manually to start B side recording. Player sends out signal to restart recording and starts playing B side program after 4 seconds.



6. After B side program complete, player stops playing and clears edit program automatically.

- Recording with Marantz cassette deck without remote cable connection, and recording with the cassette deck other than Marantz.

1. After setting up Edit program, start recording of cassette deck first.

2. Press ► or ❚❚ buttons of the player to start A side program. Then player starts playing A side program after 4 seconds.



3. After A side program complete, player turns to the pause state at the beginning of B side program.

4. When A side of the tape ends up, Reverse cassette tape or invert recording direction manually and start recording.

5. Press ► or ❚❚ buttons of the player to start B side recording. Then player starts playing B side program after 4 seconds.



6. After B side program complete, player stops playing and clears edit program automatically.

Downloaded From Disc-Player.com Marantz Manuals

ENGLISH

Pitch control (changing the play speed)

The play speed (pitch) can be changed across a ±12 step.

∗ Digital signals are not output during pitch control.

• Increasing the play speed

Press the PITCH+ button on the remote control unit.



The “PITCH” indicator on the display lights.
Each time the button is pressed, the play speed is increased, and it is displayed on the main display.



• Reducing the play speed

Press the PITCH- button on the remote control unit.



The “PITCH” indicator on the display lights.
Each time the button is pressed, the play speed is reduced and it is displayed on the main display.



• Returning play to the normal speed

Press the PITCH RESET button on the remote control unit.



The “PITCH” indicator on the display goes off and “Pitch: 0” appears on the main display.
If the PITCH RESET button on the remote control unit is pressed again, play returns to the previous speed setting.



Downloaded From Disc-Player.com Marantz Manuals

ENGLISH

CD-TEXT

"CD-TEXT" refers to a new kind of music disc which differs from a conventional music disc in that album titles, track titles and other text information are recorded on it. CDs with the following logos support this function.

The text information is recorded on those parts which were not used by conventional music CDs.
This means that discs with recorded CD-TEXT can be played in the same way as in the past on existing CD players but the text information can be viewed only when they are played on a player that supports CD-TEXT.
This player automatically identifies whether a disc supports CD-TEXT, and it displays the information on the display.

Display of player



This lights when the disc that has been read is identified as supporting CD-TEXT.

The following items of the text information on CD-TEXT discs can be displayed in sequence by pressing the TEXT button on the remote control unit.
However, the recorded information differs from one disc to another so that not all the information given below will necessarily be displayed. Items not recorded are automatically omitted and skipped by the player, and only the existing items are displayed.

• During play

Each time the TEXT button on the remote control unit is pressed, the information items are displayed in the following sequence. During play, the information of track now playing is mainly displayed.


Title of track xx now playing
Album Title
xx Title (title of track xx)
xx Artist (artist of track xx)
xx Songwriter (songwriter of track xx)
xx Composer (composer of track xx)
xx Arranger (arranger of track xx)
Time display

• In the stop mode

Each time the TEXT button on the remote control unit is pressed, the information items are displayed in the following sequence. When the ► button is pressed while "-- Title" is displayed, the track concerned starts playing. The maximum of characters that can be displayed is 64.



Downloaded From Disc-Player.com Marantz Manuals

9. SPECIFICATIONS AND DIMENSIONS

ENGLISH

Specifications

Audio characteristics

Channels ..... 2 channels
Frequency response ..... 20 Hz to 20 kHz
Dynamic range ..... 100 dB
Signal-to-noise ratio ..... 110 dB
Channel separation ..... 100 dB (1 kHz)
Harmonic distortion ..... 0.0025% (1 kHz)
Wow & flutter ..... Precision of quartz
Error correction system ..... Cross-interleave Reed Solomon code (CIRC)
Audio output ..... 2.0 V rms, stereo
Headphone output ..... 18 mW/32 ohms (variable maximum)
Digital output
Coaxial output (pin jack) ..... 0.5 Vp-p, 75 ohms
Optical output (square optical connector) ..... -19 dBm

Optical readout system

Laser ..... AlGaAs semiconductor
Wavelength ..... 780 nm

Signal system

Sampling frequency ..... 44.1 kHz
Quantization ..... 16-bit linear/channel

Power supply

N, T version ..... AC 230 V 50 Hz
Power consumption ..... 14 W

Cabinet, etc.

Maximum dimensions ..... 440 (W) x 87 (H) x 283 (D) mm
Weight ..... 4.0 kg
Allowable operating temperature ..... +5 to +35°C
Allowable operating humidity .... 5 to 90% (no condensation)

This player's specifications and exterior are subject to change without notice for improvements.

Dimensions (unit: mm)



Downloaded From Disc-Player.com Marantz Manuals

10. TROUBLESHOOTING

ENGLISH

If you think that something is wrong with your player, first check the points listed below. Incorrect operations can sometimes be taken for trouble and malfunctions. If the trouble persists even after the following points have been checked, consult your dealer or nearest Marantz sales office or service center.

Disc fails to turn.

- Has the mains cord been connected properly?
- Has the player been turned on?
- Has the disc been placed in the proper position?
- Is the disc upside down? (Is the disc's label surface facing up?)
- Is the disc dirty?
- Is the disc scratched?
- Is the disc warped?

Disc turns but no sound is heard.

- Have the amplifier and speakers been connected properly?
- Has the amplifier been turned on?
- Has the amplifier's function or selector switch been set to "CD" or "AUX" (or to whichever connectors the player has been connected)?
- Is the amplifier's volume at its lowest setting?

Disc starts turning but then stops at some point.

- Is the disc dirty?
- Is the disc scratched?
- Is the disc warped?
- Is the disc being played a music CD? CD-ROMs for personal computers, etc. cannot be played.

No remote control operations.

- Is the transmitter of the remote control unit (RC5400CD) pointed at the remote sensor of the player? Is there anything between the player and remote control unit which is blocking the signals?
- Have the batteries of the remote control unit (RC5400CD) run down?
- Is a strong light shining on the remote sensor of the player?
- Is the REMOTE CONTROL switch on the rear panel set to the EXTERNAL position? (Set it to the INTERNAL position if the player is to be used on its own.)

CD-R/CD-RW discs cannot be played.

- Has the disc been placed upside down on the disc tray?
- Is the recorded information in a format (CD-DA) used for music applications?
- Has the disc been finalized? If it is not finalized (closed), it cannot be played.

Downloaded From Disc-Player.com Marantz Manuals

www.marantz.com

You can find your nearest authorized distributor or dealer on our website.

U.S.A.	Marantz America, Inc.	1100 Maplewood Drive, Itasca, IL 60143, U.S.A.
EUROPE	Marantz Europe B.V.	P.O. Box 8744, 5605 LS Eindhoven, The Netherlands

marantz® is a registered trademark.

Printed in China

07/2005 00M45BW851310 mzh-d

Downloaded From Disc-Player.com Marantz Manuals